

creativeglass



958.334 Sushi Square
9 x 9 x 2 cm



958.335 Sushi Squares 4
22.5 x 22.5 x 2 cm



958.345 Sushi Rectangular small
24 x 13 x 2 cm




958.349 Sushi Rectangular large
29 x 23.5 x 1.5 cm



958.343 China Soup Bowl
18.5 x 5 cm




958.337 China Spoon
12 x 3 x 2 cm



958.340 Yin-Yang Large
35 x 35 x 2.5 cm



958.341 Yin-Yang
30 x 30 x 2.5 cm



958.347 Breakfast Tray
38 x 23 x 2 cm




958.355 Elegance
69 x 19 x 1.4 cm



958.351 Snack Tray
24 x 17 x 1.4 cm



958.346 Candle Bridge Universal
28 x 14 cm



958.350 Double Curve small
24 x 20 x 4.5 cm



958.354 Mini Lamp Bender
15 x 15 x 5.7 cm



958.348 Pyramide
16 x 16 x 13 cm



958.342 Soft Edge 4
35 x 35 x 3 cm



958.352 Soft Edged Platter Oblong
36 x 24 x 2 cm



958.353 Soft Edged Platter Mini
16 x 16 x 1.6 cm



958.339 Retro Party Platter
42 x 30 x 4.5 cm



958.336 Retro Party Bowl
42 x 42 x 9 cm



958.356 Boat Small 32 x 9.5 x 2 cm
958.344 Boat Medium 44.5 x 12 x 3.8 cm
958.357 Boat Large 58 x 16.5 x 3.5 cm

Creative Glass AG
Geerenstrasse 13
CH-8604 Volketswil
Tel. +41 44 908 1155
Fax. +41 44 946 1231
info@creative-glass.com

Creative Glass
Kienzlstrasse 13
A-4600 Wels
Tel. +43 7242 712 28
Fax +43 7242 712 288
creative-glass-a@merlin.at

Creative Glass
12 Sextant Park
Medway City Estate
Rochester, Kent ME2 4LU
Tel. +44 1 634 735 416
Fax +44 1 634 295 734
creativeglassuk@btconnect.com